

DRAUGHT FAUCET CLEANING



1
Un-tap keg from barrel. Remove beer faucet (with a spanner wrench) and take apart.



2
Place faucet in bucket of beer-line cleaner to soak.



3
Scrub beer faucet and parts with brush—inside and out.



4
Rinse faucet and parts with cool, fresh water. Check to see if faucet parts need repair.



5
Assemble rinsed faucet parts and connect faucet to shank.



6
Tap keg, draw beer to test.